

MaxxFan™ 1-Switch Wall Control Operating Guide

The Customer Service Phone Number for MaxxAir is 800-780-9893, e-mail is custservice@maxxair.com

MaxxFan™ 1-Switch Wall Control Model Series 01000K

For use with MaxxFan Deluxe models 5100K thru 8501K & MaxxFan™ Standard models 4000K thru 4801K



Wall Control Features

- Turns Fan On or Off from convenient wall location
- Keypad controls at ceiling remain active

Fan ON	Turns the Fan Motor ON at the last selected speed
Fan OFF	Turns the Fan Motor OFF



www.maxxair.com

1.800.780.9893

MaxxFan™ 1-Switch Wall Control Installation Guide

The Customer Service Phone Number for MaxxAir is 800-780-9893, e-mail is custservice@maxxair.com

MaxxFan™ 1-Switch Wall Control Model Series 01000K

For use with MaxxFan Deluxe models 5100K thru 8501K & MaxxFan™ Standard models 4000K thru 4801K




Step 1. Cut a 1 5/8" x 1 1/4" rectangular hole in the wall where you wish to mount the 1-Switch Wall Control.




Step 3. Plug end of RJ-11 cable into RJ-11 jack on 1-Switch Wall Control PCB. Note arrow & 'Up' marking on PCB for proper orientation.



Step 4. Attach the Wall Control to wall with appropriate screws for wall construction



The black RJ-11 jack is for other controls



Step 2. Plug one end of RJ-11 cable into GRAY RJ-11 jack on MaxxFan PCB (at ceiling)
(The black RJ-11 jack is for other controls).

Step 2A. Route RJ-11 cable thru wall to hole cut in step 1.



Step 5. Snap Bezel onto Wall Control.